

Installation Guide Premium European Vinyl 5.00mm

Vodič za instalaciju Premium Evropski vinil 5.00mm

Please inspect each plank and approve all products before installation. Claims will not be accepted if the products are installed with visible defects.

Do not install over carpet or soft padded flooring.

TOOLS REQUIRED: Utility knife, tape measure, square angle, rubber mallet, tapping block.

INSTALLATION:

While installing SPC flooring isn't particularly difficult, certain mistakes can lead to headaches and expensive repairs down the line. Remember, SPC flooring will expand with temperature changes, so you must leave a 13mm gap along any walls or obstructions like a post, kitchen cabinet etc. Acclimation is typically unnecessary unless the boxes were stored in temperatures much lower than standard room temperature. Make sure the floors are level to within 13mm within 1,8m. Transition pieces should be installed if the floor is longer than 18m. Be cautious of excessive moisture beneath the flooring, as it can lead to mold growth

Take necessary precautions:

1. Begin by laying down three rows of planks along the wall. Avoid using the wall as a backstop, as it may not be perfectly straight. Instead, use scrap planks to secure these rows parallel to your starting wall.
2. To connect the planks, lift them at 15–20-degree angle and gently push them into grooves. Once the plank is properly engaged, it will lie flat without any gaps at the joints. Ensure the locking system is clean and free of debris, as this can prevent proper engagement.
3. As you continue laying more rows, regularly check for gaps between the planks. A gap in one row will lead to gaps in subsequent rows. Catching and correcting this early is crucial for a successful installation.

AFTER INSTALLATION:

1. Remove any spacers that were used and proceed install the transition molding. Make sure the moldings are not attached to the planks; instead, fasten the transition moldings to the subfloor and secure the wall trim to the wall.
2. Place suitable floor protectors or coasters under all furniture legs.
3. Refrain from using polishers, waxes, or harsh chemicals for cleaning.
4. Prolonged exposure to sunlight can affect most flooring and furniture. If possible, use drapes on windows to minimize exposure.

Molimo vas da pregledate svaku dasku i odobrite sve proizvode prije ugradnje. Reklamacije neće biti prihvaćene ako su proizvodi ugrađeni s vidljivim nedostacima.

Nemojte ugrađivati preko tepiha ili mekane podloge.

POTREBAN ALAT: Rezač, metar, kutnik, gumeni čekić, drveni blok za udaranje.

UGRADNJA:

Iako postavljanje SPC poda nije posebno teško, određene greške mogu dovesti do problema i skupih popravaka. Zapamtite, SPC pod će se širiti s promjenama temperature, pa morate ostaviti razmak od 13mm uz zidove ili prepreke poput stubova, kuhinjskih ormarića itd. Aklimatizacija obično nije potrebna osim ako su kutije bile skladištene na temperaturama znatno nižim od standardne sobne temperature. Pobrinite se da su podovi ravni u toleranciji od 13mm na 1,8m. Prijelazni komadi trebaju biti ugrađeni ako je pod duži od 18m. Budite oprezni s viškom vlage ispod poda, jer to može dovesti do rasta plijesni.

Poduzmite potrebne mjere opreza:

1. Počnite postavljanjem tri reda dasaka duž zida. Izbjegavajte korištenje zida kao oslonca, jer možda nije potpuno ravan. Umjesto toga, upotrijebite ostatke dasaka da osigurate ove redove paralelno sa zidom od kojeg započinjete.
2. Da biste spojili daske, podignite ih pod kutom od 15–20 stepeni i nježno ih gurnite u utore. Kada se daska pravilno spoji, ležat će ravno bez ikakvih praznina na spojevima. Uvjerite se da je sistem zaključavanja čist i bez ostataka, jer to može spriječiti pravilno povezivanje.
3. Dok nastavljate postavljati više redova, redovno provjeravajte ima li praznina između dasaka. Praznina u jednom redu će uzrokovati praznine u narednim redovima. Otkrivanje i ispravljanje toga na vrijeme je ključno za uspješnu ugradnju.

NAKON UGRADNJE:

1. Uklonite sve razmaknice koje su korištene i nastavite s postavljanjem prijelaznih lajsni. Pazite da lajsne ne budu pričvršćene za daske; umjesto toga, pričvrstite prijelazne lajsne za podlogu, a zidne lajsne učvrstite za zid.
2. Postavite odgovarajuće zaštitne podloge ili podmetače ispod svih nogu namještaja.
3. Suzdržite se od korištenja polirki, voskova ili agresivnih hemikalija za čišćenje.
4. Dugotrajna izloženost sunčevoj svjetlosti može utjecati na većinu podova i namještaja. Ako je moguće, koristite zavjese na prozorima kako biste smanjili izloženost.